

| Gels - Color Macros for DMX | | |
|-----------------------------|-------------------|----------------|
| DMX value | Gel Name | Color Number |
| 000-005 | no function | |
| 006-008 | Red | 100% Red LED |
| 009-011 | Fire | LEE 019 |
| 012-014 | Medium Red | LEE 027 |
| 015-017 | Primary Red | LEE 106 |
| 018-020 | Med Amber | LEE 020 |
| 021-023 | Dark Amber | LEE 022 |
| 024-026 | Deep Amber | LEE 104 |
| 027-029 | Orange | LEE 105 |
| 030-032 | Deep Golden Amber | LEE 135 |
| 033-035 | Yellow | LEE 101 |
| 036-038 | Green | 100% Green LED |
| 039-041 | Lime Green | LEE 088 |
| 042-044 | Moss Green | LEE 089 |
| 045-047 | LEE Green | LEE 121 |
| 048-050 | Primary Green | LEE 139 |
| 051-053 | Jas Green | LEE 738 |
| 054-056 | Jade | LEE 323 |
| 057-059 | Blue | 100% Blue LED |
| 060-062 | Sky Blue | LEE 068 |
| 063-065 | Tokyo Blue | LEE 071 |
| 066-068 | Light Blue | LEE 118 |
| 069-071 | Marine Blue | LEE 131 |
| 072-074 | Med Blue | LEE 132 |
| 075-077 | Congo Blue | LEE 181 |
| 078-080 | Mikkel Blue | LEE 716 |
| 081-083 | Rose Pink | LEE 002 |
| 084-086 | Med Pink | LEE 036 |
| 087-089 | Light Lavender | LEE 052 |
| 090-092 | Lavender | LEE 058 |
| 093-095 | Magenta | LEE 113 |
| 096-098 | Mauve | LEE 126 |
| 099-101 | Smokey Pink | LEE 127 |

| Gels - Color Macros for DMX | | |
|-----------------------------|------------------------------------|----------------|
| DMX value | Gel Name | Color Number |
| 102-104 | Special Med Lavender | LEE 343 |
| 105-107 | Ultimate Violet | LEE 707 |
| 108-110 | Magical Magenta | LEE 795 |
| 111-113 | Chrysalis Pink | LEE 798 |
| 114-116 | Specia KH Lavender | LEE 799 |
| 117-119 | Bulb White | 2700K |
| 120-122 | Halogen White | 3200K |
| 123-125 | Neutral White | 4200K |
| 126-128 | Daylight White | 5600K |
| 129-131 | Cold White I | 6000K |
| 132-134 | Cold White II | 6300K |
| 135-137 | White (only if available) | 100% White LED |
| 138-140 | Amber (only if available) | 100% Amber LED |
| 141-143 | Lime (only if available) | 100% Lime LED |
| 144-146 | Cyan (only if available) | 100% Cyan LED |
| 147-149 | User Color 1 | |
| 150-152 | User Color 2 | |
| 153-155 | User Color 3 | |
| 156-158 | User Color 4 | |
| 159-161 | User Color 5 | |
| 162-164 | Color Jumping stop | |
| 165-209 | Color Jumping speed slow @ fast | color 1-37 |
| 210-255 | Color fading speed slow @ fast | color 1-37 |

Gels - Color Macros for Standalone Mode

| Position | Gel Name | Color Number |
|----------|-------------------|----------------|
| 1 | Red | 100% Red LED |
| 2 | Fire | LEE 019 |
| 3 | Medium Red | LEE 027 |
| 4 | Primary Red | LEE 106 |
| 5 | Med Amber | LEE 020 |
| 6 | Dark Amber | LEE 022 |
| 7 | Deep Amber | LEE 104 |
| 8 | Orange | LEE 105 |
| 9 | Deep Golden Amber | LEE 135 |
| 10 | Yellow | LEE 101 |
| 11 | Green | 100% Green LED |
| 12 | Lime Green | LEE 088 |
| 13 | Moss Green | LEE 089 |
| 14 | LEE Green | LEE 121 |
| 15 | Primary Green | LEE 139 |
| 16 | Jas Green | LEE 738 |
| 17 | Jade | LEE 323 |
| 18 | Blue | 100% Blue LED |
| 19 | Sky Blue | LEE 068 |
| 20 | Tokyo Blue | LEE 071 |
| 21 | Light Blue | LEE 118 |
| 22 | Marine Blue | LEE 131 |
| 23 | Med Blue | LEE 132 |
| 24 | Congo Blue | LEE 181 |
| 25 | Mikkel Blue | LEE 716 |
| 26 | Rose Pink | LEE 002 |
| 27 | Med Pink | LEE 036 |
| 28 | Light Lavender | LEE 052 |

Gels - Color Macros for Standalone Mode

| Position | Gel Name | Color Number |
|----------|---------------------------|----------------|
| 29 | Lavender | LEE 058 |
| 30 | Magenta | LEE 113 |
| 31 | Mauve | LEE 126 |
| 32 | Smokey Pink | LEE 127 |
| 33 | Special Med Lavender | LEE 343 |
| 34 | Ultimate Violet | LEE 707 |
| 35 | Magical Magenta | LEE 795 |
| 36 | Chrysalis Pink | LEE 798 |
| 37 | Specia KH Lavender | LEE 799 |
| 38 | Bulb White | 2700K |
| 39 | Halogen White | 3200K |
| 40 | Neutral White | 4200K |
| 41 | Daylight White | 5600K |
| 42 | Cold White I | 6000K |
| 43 | Cold White II | 6300K |
| 44 | White (only if available) | 100% White LED |
| 45 | Amber (only if available) | 100% Amber LED |
| 46 | Lime (only if available) | 100% Lime LED |
| 47 | Cyan (only if available) | 100% Cyan LED |

Gels - Color Macros for Back Plate Knob-Operation

| Position | Gel Name | Color Number | |
|----------|---------------------------|----------------|-------------------------------------|
| 1 | Red | 100% Red LED | |
| 2 | Medium Red | LEE 027 | |
| 3 | Primary Red | LEE 106 | |
| 4 | Med Amber | LEE 020 | |
| 5 | Dark Amber | LEE 022 | |
| 6 | Orange | LEE 105 | |
| 7 | Yellow | LEE 101 | |
| 8 | Green | 100% Green LED | |
| 9 | Moss Green | LEE 089 | |
| 10 | Primary Green | LEE 139 | |
| 11 | Jas Green | LEE 738 | |
| 12 | Jade | LEE 323 | |
| 13 | Blue | 100% Blue LED | |
| 14 | Sky Blue | LEE 068 | |
| 15 | Congo Blue | LEE 181 | |
| 16 | Mikkel Blue | LEE 716 | |
| 17 | Rose Pink | LEE 002 | |
| 18 | Lavender | LEE 058 | |
| 19 | Magenta | LEE 113 | |
| 20 | Mauve | LEE 126 | |
| 21 | Smokey Pink | LEE 127 | |
| 22 | Special Med Lavender | LEE 343 | |
| 23 | Amber (only if available) | 100% Amber LED | if not available use no function |
| 24 | Lime (only if available) | 100% Lime LED | if not available use no function |
| 25 | Cyan (only if available) | 100% Cyan LED | if not available use no function |

